

Studio 49 Barred Instrument Replacement Parts Guide						
500 Series	Easycussion					
	AX 500	AG 500	AM 500			
	Pins	EX-03	EG-03			
Tubing	EX-02	EG-02	EM-02			
1000 Series	Xylophone Rosewood			Xylophone Grillodur		
	SX / H-SX 1000	AX / H-AX 1000	BX / H-BX 1000	SXG 1000	AXG 1000	BXG 1000
	Bar	XR-01 #__	XR-01 #__	BXR-01 #__	XGN-01 #__	XGN-01 #__
Pins	1000-PX-03	1000-PX-03		1000-PX-03	1000-PX-03	
Tubing	1000-AFG-03	1000-AFG-04		1000-AFG-03	1000-AFG-04	
Mallet	CS 5	CS 44	CS 7	CS 55	CS 44	CS 7
1000 Series	Metallophone					
	SM / H-SM 1000	AM / H-AM 1000	BM 1000			
	Bar	ME-01 #__	ME-01 #__			
Pins	PM-03	PM-03				
Tubing	1000-AFG-03	1000-AFG-05				
Mallet	CS 55	CS 7	CS 7			
1600 Series	Glockenspiel					
	GSd / GSc	GAd / H-GA	GT			
	Bar	G-01 #__	G-01 #__			
Pins	AG-03	AG-03	AG-03			
Tubing	1000-AFG-02	1000-AFG-02	1000-AFG-02			
Mallet	GS	PKS 3	PKS 3			
1600 Series	Xylophone Rosewood			Metallophone		
	SX / H-SX 1600	AX / H-AX 1600	BX / H-BX 1600	SM / H-SM 1600	AM / H-AM 1600	BM / H-BM 1600
	Bar	XR-01 #__	XR-01 #__	BXR-01 #__	ME-01 #__	ME-01 #__
Pins	AX-03	AX-03	AX-03	AM-03	AM-03	AM-03
Tubing	XM-05	XM-05	XM-07	XM-05	AM-02	XM-08
Mallet	S 5	S 4	S 33	S 55	S 7	S 33
2000 Series	Glockenspiel			Metallophone		
	SGd / H-SG	AGd / H-AG	SGc / AGc	SM / H-SM 2000	AM / H-AM 2000	BM / H-BM 2000
	Bar	AG/SG-01 #__	AG/SG-01 #__	AG/SG-01 #__	M-01 #__	M-01 #__
Pins	AG-03	AG-03	AG-03	AM-03	AM-03	BM-03
Tubing	AG-02	AG-02	AG-02	AM-02	AM-02	XM-02
Mallet	S 1	S 2	S 1 / S 2	S 50	S 7	S 3
2000 Series	Xylophone Rosewood			Xylophone Grillodur		
	SX / H-SX 2000	AX / H-AX 2000	BX / H-BX 2000	SXG / H-SXG 2000	AXG / H-AXG 2000	BXG / H-BXG 2000
	Bar	X-01 #__	X-01 #__	BX-01 #__	XG-01 #__	XG-01 #__
Pins	AX-03	AX-03	BX-03	AX-03	AX-03	BX-03
Tubing	XM-05	XM-05	XM-02	XM-05	XM-05	XM-02
Mallet	S 5	S 4	S 3	S 50	S 40	S 3
Vintage	Xylophone			Metallophone		
	SXd / AXd	H-SXd / H-AXd	BXd	SMd / AMd	H-SMd / H-AMd	BMd
	Bar	X-01 #__	X-01 #__	BX-01 #__	M-01 #__	M-01 #__
Pins	A/SX-3	A/SX-3	BXM-3	A/SM-3	A/SM-3	BXM-3
Tubing strips	AX-05	AX-06		AM-05	AM-06	