

| Studio 49 Barred Instrument Replacement Parts Guide | | | | | | |
|---|--------------------|----------------|----------------|---------------------|------------------|------------------|
| 500 Series | Easycussion | | | | | |
| | AX 500 | AG 500 | AM 500 | | | |
| | Pins | EX-03 | EG-03 | | | |
| Tubing | EX-02 | EG-02 | EM-02 | | | |
| 1000 Series | Xylophone Rosewood | | | Xylophone Grillodur | | |
| | SX / H-SX 1000 | AX / H-AX 1000 | BX / H-BX 1000 | SXG 1000 | AXG 1000 | BXG 1000 |
| | Bar | XR-01 #__ | XR-01 #__ | BXR-01 #__ | XGN-01 #__ | XGN-01 #__ |
| Pins | 1000-PX-03 | 1000-PX-03 | | 1000-PX-03 | 1000-PX-03 | |
| Tubing | 1000-AFG-03 | 1000-AFG-04 | | 1000-AFG-03 | 1000-AFG-04 | |
| Mallet | CS 5 | CS 44 | CS 7 | CS 55 | CS 44 | CS 7 |
| 1000 Series | Metallophone | | | | | |
| | SM / H-SM 1000 | AM / H-AM 1000 | BM 1000 | | | |
| | Bar | ME-01 #__ | ME-01 #__ | | | |
| Pins | PM-03 | PM-03 | | | | |
| Tubing | 1000-AFG-03 | 1000-AFG-05 | | | | |
| Mallet | CS 55 | CS 7 | CS 7 | | | |
| 1600 Series | Glockenspiel | | | | | |
| | GSd / GSc | GAd / H-GA | GT | | | |
| | Bar | G-01 #__ | G-01 #__ | | | |
| Pins | AG-03 | AG-03 | AG-03 | | | |
| Tubing | 1000-AFG-02 | 1000-AFG-02 | 1000-AFG-02 | | | |
| Mallet | GS | PKS 3 | PKS 3 | | | |
| 1600 Series | Xylophone Rosewood | | | Metallophone | | |
| | SX / H-SX 1600 | AX / H-AX 1600 | BX / H-BX 1600 | SM / H-SM 1600 | AM / H-AM 1600 | BM / H-BM 1600 |
| | Bar | XR-01 #__ | XR-01 #__ | BXR-01 #__ | ME-01 #__ | ME-01 #__ |
| Pins | AX-03 | AX-03 | AX-03 | AM-03 | AM-03 | AM-03 |
| Tubing | XM-05 | XM-05 | XM-07 | XM-05 | AM-02 | XM-08 |
| Mallet | S 5 | S 4 | S 33 | S 55 | S 7 | S 33 |
| 2000 Series | Glockenspiel | | | Metallophone | | |
| | SGd / H-SG | AGd / H-AG | SGc / AGc | SM / H-SM 2000 | AM / H-AM 2000 | BM / H-BM 2000 |
| | Bar | AG/SG-01 #__ | AG/SG-01 #__ | AG/SG-01 #__ | M-01 #__ | M-01 #__ |
| Pins | AG-03 | AG-03 | AG-03 | AM-03 | AM-03 | BM-03 |
| Tubing | AG-02 | AG-02 | AG-02 | AM-02 | AM-02 | XM-02 |
| Mallet | S 1 | S 2 | S 1 / S 2 | S 50 | S 7 | S 3 |
| 2000 Series | Xylophone Rosewood | | | Xylophone Grillodur | | |
| | SX / H-SX 2000 | AX / H-AX 2000 | BX / H-BX 2000 | SXG / H-SXG 2000 | AXG / H-AXG 2000 | BXG / H-BXG 2000 |
| | Bar | X-01 #__ | X-01 #__ | BX-01 #__ | XG-01 #__ | XG-01 #__ |
| Pins | AX-03 | AX-03 | BX-03 | AX-03 | AX-03 | BX-03 |
| Tubing | XM-05 | XM-05 | XM-02 | XM-05 | XM-05 | XM-02 |
| Mallet | S 5 | S 4 | S 3 | S 50 | S 40 | S 3 |
| Vintage | Xylophone | | | Metallophone | | |
| | SXd / AXd | H-SXd / H-AXd | BXd | SMd / AMd | H-SMd / H-AMd | BMd |
| | Bar | X-01 #__ | X-01 #__ | BX-01 #__ | M-01 #__ | M-01 #__ |
| Pins | A/SX-3 | A/SX-3 | BXM-3 | A/SM-3 | A/SM-3 | BXM-3 |
| Tubing strips | AX-05 | AX-06 | | AM-05 | AM-06 | |